

Installation Instructions for NVCC8783MXLTRK

Parts needed for this installation:

- 2- 32'' aluminum rails
 - 3- 36'' aluminum rails
 - 10- screws (style #90899)
-

Installing side aluminum rails:

Note: use 1-32'' and 1-36'' rail butted up against each other

Note: Your canopy has screw holes in it installed by the manufacturer.

1. Place 1- 32'' rail up against canopy with channel facing down. Front of rail should be 1 ½'' from the 1st hole in the front of the canopy .
2. Mark this hole on the rail. Drill the marked hole using a 3/8'' drill bit.
3. Align hole in rail with 1st hole in the canopy and secure using screws provided
4. Place 1- 36'' rail touching front track Once again the channel is facing down. Mark the hole on the front of the rail as well as the hole in the back of the rail. Repeat steps 2 and 3 .
5. Repeat the above process to install the rail on the opposite side.

Installing back aluminum rail:

1. Center the remaining 36'' rail on the back of the canopy by placing the center of the rail over the center between the 2 drill holes on the canopy.
Channel is still facing down.
2. Mark holes, drill using 3/8'' bit and secure using the screws provided just like you did on the side rails.