



**PARTS CATALOG  
GOLF CAR  
2017 DRIVE<sup>2</sup> DR2A17 PTV  
(J0D1)**

Applicable Serial No.  
Engine Serial No.



Frame Serial No.




---


**STARTING SERIAL NO.  
DRIVE<sup>2</sup> DR2A17 PTV  
J0D-000101**

# ENGINE 1

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-19001-10-00	ENGINE ASSEMBLY	1	



  
JC04110-L010




# CYLINDER HEAD

Ref No.	Part Number	Description	Qty	Remarks
1	JT0-11111-00-00	HEAD, CYLINDER 1	1	
2	JN6-11133-10-00	..GUIDE, VALVE 1	2	
3	JT0-11181-00-00	GASKET, CYLINDER HEAD 1	1	
4	97012-10070-00	BOLT	4	
5	90201-10057-00	WASHER, PLATE	4	
6	99530-14016-00	PIN, DOWEL	2	
7	95622-08618-00	BOLT, STUD	2	
8	BPR-4ES00-04-00	PLUG, SPARK (NGK BPR4ES)	1	AP
8	BPR-2ES00-00-00	PLUG, SPARK (NGK-BPR2ES)	1	STD
9	JN6-11191-01-00	COVER, CYLINDER HEAD 1	1	
10	JN6-11116-00-00	..JOINT, BREATHER	1	
11	JN6-11168-00-00	COVER, BREATHER	1	
12	JN6-11169-00-00	GASKET, BREATHER COVER	1	
13	JN6-11193-00-00	GASKET, HEAD COVER 1	1	
14	95822-06030-00	BOLT, FLANGE	4	
15	90462-05061-00	CLAMP	1	
16	J0B-E1166-00-00	PIPE, BREATHER 1	1	
17	95602-08710-00	BOLT, STUD	2	
18	JR7-11163-10-00	ELEMENT	1	
19	90467-13847-00	CLIP	2	



J0B1110-S010

# CRANKSHAFT & PISTON




Ref No.	Part Number	Description	Qty	Remarks
1	JN6-11400-00-00	CRANKSHAFT ASSY	1	
2	JR7-11631-00-A0	PISTON (STD)	1	
2	JR7-11635-00-00	PISTON (0.25MM O/S)	1	AP
2	JR7-11636-00-00	PISTON (0.50MM O/S)	1	AP
3	JR7-11610-00-00	PISTON RING SET (STD)	1	
3	JR7-11610-10-00	PISTON RING SET (0.25MM O/S)	1	AP
3	JR7-11610-20-00	PISTON RING SET (0.50MM O/S)	1	AP
4	583-11633-00-00	PIN, PISTON	1	
5	93450-21053-00	CIRCLIP	2	
6	JN6-11650-10-00	CONNECTING ROD ASSY	1	
7	JN6-11654-10-00	. .BOLT, CONNECTING ROD	2	
8	JN6-11454-10-00	WEIGHT 1	1	



JN7010-6021

# CAMSHAFT & VALVE





Ref No.	Part Number	Description	Qty	Remarks
1	JR7-12170-00-00	CAMSHAFT ASSY 1	1	
2	JN6-12111-10-00	VALVE, INTAKE	1	
3	7RH-12121-10-00	VALVE, EXHAUST	1	
4	JN6-12153-10-00	LIFTER, VALVE	2	
5	90501-264A9-00	SPRING, COMPRESSION	2	
6	J38-12117-01-00	RETAINER, VALVE SPRING	2	
7	J38-12118-00-00	LOCK, VALVE SPRING RETAINER	2	
8	JN6-12151-10-00	ARM, VALVE ROCKER	2	
9	22F-12159-10-00	SCREW, VALVE ADJUSTING	2	
10	90170-05302-00	NUT	2	
11	J38-12156-20-00	SHAFT, ROCKER 2	1	
12	JR7-12154-10-00	ROD, VALVE PUSH	2	
13	4G0-12119-00-00	SEAL, VALVE STEM	1	



JD13110-K030

## AIR SHROUD & FAN



Ref No.	Part Number	Description	Qty	Remarks
1	JN6-12621-02-00	CASE, FAN	1	
2	95802-06020-00	BOLT, FLANGE	4	
3	JN6-12651-01-00	AIR SHROUD, CYLINDER 1	1	
4	JR7-12658-00-00	DAMPER, AIR SHROUD 1	1	
5	JN6-12652-00-00	AIR SHROUD, CYLINDER 2	1	
6	95802-06020-00	BOLT, FLANGE	2	
7	J0B-E2691-00-00	DUCT 1	1	
8	90269-10001-00	RIVET	1	
9	JR7-12634-00-00	PLATE 2	1	




J0B1110-S040

# INTAKE 1

Ref No.	Part Number	Description	Qty	Remarks
1	JC0-13595-00-00	JOINT	1	
2	95702-08500-00	NUT, FLANGE	2	
3	JN6-13567-00-00	GASKET	1	
4	JC0-13567-00-00	GASKET	1	
5	JN6-13567-00-00	GASKET	1	
6	95802-06016-00	BOLT, FLANGE	2	
7	91702-05010-00	PIN, CLEVIS	2	
8	90468-10049-00	CLIP	2	
9	99001-07600-00	CIRCLIP	1	
10	J0B-E4412-00-00	CAP, CLEANER CASE 1	1	
11	J0B-E4451-01-00	ELEMENT, AIR CLEANER	1	
12	JU0-E445E-00-00	FILTER 1	1	
13	J0B-E4411-01-00	CASE, AIR CLEANER 1	1	
14	3B4-14424-00-00	CLIP, CAP FITTING	7	
15	J0B-F6312-00-00	CABLE, THROTTLE 2	1	
16	J0B-E4413-00-00	STAY	1	
17	97702-60416-00	SCREW, TAPPING	2	
18	J0B-E5471-00-00	DUCT, AIR	1	
19	90105-06057-00	BOLT, FLANGE	2	
20	97702-50016-00	SCREW, TAPPING	2	


CONTINUED ON NEXT FRAME >



**FWD**  
J0B1110-S050

# INTAKE 1


Ref No.	Part Number	Description	Qty	Remarks
21	J0B-E4437-00-00	DUCT	1	
22	90467-24140-00	CLIP	1	
23	J0B-E4453-01-00	JOINT, AIR CLEANER 1	1	



 J0B1110-S050



## INTAKE 2




Ref No.	Part Number	Description	Qty	Remarks
1	J0B-13750-00-00	THROTTLE BODY ASSY	1	
2	1C7-82380-00-00	..SENSOR, PRESSURE	1	
3	JC0-13542-00-00	..HOSE, VACUUM SENSING 1	1	
4	98502-06014-00	..SCREW, PAN HEAD	2	
5	J0B-13770-00-00	..INJECTOR ASSY	1	
6	52S-13938-00-00	...PIPE	1	
7	52B-14137-00-00	...CLIP	1	
8	52B-14147-00-00	...O-RING	1	
9	5CA-14147-00-00	...O-RING	1	
10	95812-06025-00	..BOLT, FLANGE	1	



J0B1110-S060


# EXHAUST

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-E4710-01-00	MUFFLER ASSY 1	1	
2	J0B-F1436-00-00	BRKT., MUFF. 2	1	
3	7KY-14613-01-00	GASKET, EXHAUST 1	1	
4	JW1-E4713-00-00	NUT, MUFFLER JOINT	2	
5	95822-08020-00	BOLT, FLANGE	2	
6	95702-08500-00	NUT, FLANGE	1	
7	J0B-14430-00-00	DUCT ASSY	1	
8	90464-09823-00	CLAMP	1	



  
J0B1110-S070

# CRANKCASE




Ref No.	Part Number	Description	Qty	Remarks
1	JC0-15111-01-00	CRANKCASE 1	1	
2	93306-30709-00	BEARING	1	
3	93102-35014-00	OIL SEAL	1	
4	93306-20201-00	BEARING	1	
5	90340-12097-00	PLUG, STRAIGHT SCREW	1	
6	812-11198-00-00	GASKET	1	
7	99530-08016-00	PIN, DOWEL	2	
8	JN6-15411-01-00	COVER, CRANKCASE 1	1	
9	93306-20714-00	BEARING	1	
10	93102-35014-00	OIL SEAL	1	
11	93306-20201-00	BEARING	1	
12	JY2-15451-00-00	GASKET, CRANKCASE COVER 1	1	
13	95812-08045-00	BOLT, FLANGE	6	
14	97012-10050-00	BOLT	2	
15	90201-10057-00	WASHER, PLATE	2	
16	796-15363-01-00	PLUG, OIL	1	
17	93210-22344-00	O-RING	1	
18	J38-15361-00-00	GAUGE, LEVEL	1	

  
JC04110-L090

# ENGINE BRACKET

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-F1411-00-00	BRACKET, ENGINE 1	2	
2	95812-10020-00	BOLT, FLANGE	4	
3	90201-10072-00	WASHER, PLATE	4	
4	J0B-F1419-01-00	BRACKET, ENGINE 2	1	
5	JT0-21481-00-00	BOLT, ENGINE MOUNTING 1	4	
6	92902-10200-00	WASHER	4	
7	95602-10200-00	NUT, S/L FLANGE	4	
8	J0B-F1485-00-00	DAMPER, RUBBER 1	4	
9	95602-10200-00	NUT, S/L FLANGE	8	




**FWD**  
J0B1110-S090

# REAR ARM & SUSPENSION

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-F2110-02-00	REAR ARM COMP.	1	
2	95822-10020-00	BOLT, FLANGE	4	
3	J0B-F1531-00-00	BOLT	2	
4	J0B-F8218-00-00	SEAL 1	1	
5	J0B-F8228-00-00	SEAL 2	2	
6	J0B-F8238-00-00	SEAL 3	2	
7	J0B-F8268-00-00	SEAL 4	2	
8	J0B-F8278-00-00	SEAL 5	2	
9	J0B-F2210-00-00	SHOCK ABSORBER ASSY, REAR	1	
10	J0B-F53A1-01-00	KNUCKLE, REAR	1	
11	93306-00622-00	BEARING	1	
12	93306-006Y4-00	BEARING	1	
13	93106-38046-00	OIL SEAL	1	
14	J0B-F3113-00-00	COLLAR	1	
15	90381-17800-00	BUSH, SOLID	2	
16	J0B-F537W-00-00	BRACKET 1	1	
17	95812-12055-00	BOLT, FLANGE	1	
18	95602-12200-00	NUT, SELF-LOCKING	1	
19	95812-08060-00	BOLT, FLANGE	1	
20	95702-08500-00	NUT, FLANGE	1	


CONTINUED ON NEXT FRAME >



# REAR ARM & SUSPENSION

Ref No.	Part Number	Description	Qty	Remarks
21	J0B-F2210-00-00	SHOCK ABSORBER ASSY, REAR	1	
22	J0B-F53A1-01-00	KNUCKLE, REAR	1	
23	93306-00622-00	BEARING	1	
24	93306-006Y4-00	BEARING	1	
25	93106-38046-00	OIL SEAL	1	
26	J0B-F3113-00-00	COLLAR	1	
27	90381-17800-00	BUSH, SOLID	2	
28	J0B-F537W-00-00	BRACKET 1	1	
29	95812-12055-00	BOLT, FLANGE	1	
30	95602-12200-00	NUT, SELF-LOCKING	1	
31	95812-08060-00	BOLT, FLANGE	1	
32	95702-08500-00	NUT, FLANGE	1	
33	95812-10055-00	BOLT, FLANGE	2	
34	95602-10200-00	NUT, S/L FLANGE	2	
35	J0B-F2171-01-00	ARM, REAR 1	2	
36	J0B-K8254-00-00	PAD, SILENCER 4	2	
37	5KM-23448-00-00	SPACER	2	
38	5UG-23517-10-00	COVER, THRUST 1	4	
39	90105-10185-00	BOLT, FLANGE	2	
40	90185-10012-00	NUT, SELF-LOCKING	2	


CONTINUED ON NEXT FRAME >




J0B1110-S100

# REAR ARM & SUSPENSION

Ref No.	Part Number	Description	Qty	Remarks
41	2HR-23526-00-00	.BUSH	4	
42	90105-10267-00	BOLT, FLANGE	4	
43	95602-10200-00	NUT, S/L FLANGE	4	



FWD  
JOB1110-S100




# FRAME

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-F2501-00-00	FRAME COMP.	1	
2	J0B-F255G-00-00	MEMBER, SEAT SUPPORT	1	
3	95812-08040-00	BOLT, FLANGE	2	
4	J0B-F253B-00-00	STAY, RELAY	1	
5	90105-08867-00	BOLT, FLANGE	1	
6	J0B-F7413-01-00	COVER, FOOTREST	1	
7	J0D-F7411-01-00	FOOTREST 1	1	
8	90269-09003-00	RIVET	2	
9	J0B-F1738-00-00	BOLT	1	
10	J0B-F1738-00-00	BOLT	1	
11	J0B-F1738-00-00	BOLT	7	
12	J0B-F258E-00-00	SUPPORT, FRONT COWL	1	
13	90105-08867-00	BOLT, FLANGE	2	
14	J0B-F2127-00-00	SHIM	1	
15	J0B-K816M-00-00	REAR STORAGE BOX COMP.	2	
16	90105-088B6-00	BOLT, FLANGE	4	
17	J0B-F258R-00-00	PLATE, BATTERY 3	1	
18	J0B-K8252-00-00	PAD, SILENCER 2	1	
19	90105-08867-00	BOLT, FLANGE	2	
20	J0B-F3123-01-00	COVER, UNDER 1	1	

CONTINUED ON NEXT FRAME >






# FRAME

Ref No.	Part Number	Description	Qty	Remarks
21	J0B-K8256-00-00	PAD, SILENCER 6	1	
22	J0B-K8257-00-00	PAD, SILENCER 7	1	
23	J0B-K8258-00-00	PAD, SILENCER 8	1	
24	J0B-F3133-02-00	COVER, LOWER 2	1	
25	J0B-K8259-00-00	PAD, SILENCER 9	1	
26	J0B-K825A-00-00	PAD, SILENCER 10	1	
27	J0B-K825E-00-00	PAD, SILENCER 11	1	
28	J0B-F1738-00-00	BOLT	6	
29	J0B-F125J-00-00	PIPE, DRAIN	2	
30	90464-76800-00	CLAMP	2	

# FRONT SUSPENSION & WHEEL

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-F3570-10-00	FRONT LOWER ARM COMP. (LEFT)	2	
2	90381-18801-00	. .BUSH, SOLID	2	
3	2HR-23526-00-00	. .BUSH	2	
4	JU0-F3511-20-00	KNUCKLE, STEERING 1	1	
5	JW1-F3512-00-00	ARM, KNUCKLE 1	2	
6	90105-10373-00	BOLT, FLANGE	4	
7	95602-10200-00	NUT, S/L FLANGE	12	
8	90105-10219-00	BOLT, FLANGE	2	
9	2NL-23448-00-00	SPACER	2	
10	90381-17800-00	BUSH, SOLID	4	
11	2NL-23517-00-00	COVER, THRUST 1	4	
12	JU0-F3521-20-00	KNUCKLE, STEERING 2	1	
13	90105-10267-00	BOLT, FLANGE	4	
14	J0B-F3350-00-00	SHOCK ABSORBER ASSY	1	
15	90387-12016-00	COLLAR	2	
16	401-22128-01-00	COVER, THRUST 1	4	
17	95812-12080-00	BOLT, FLANGE	2	
18	95612-12100-00	NUT, U	2	
19	J0B-F3390-00-00	SHOCK ABSORBER ASSY 2	1	
20	90105-10267-00	BOLT, FLANGE	2	


CONTINUED ON NEXT FRAME >



 J0D1100-S130

# FRONT SUSPENSION & WHEEL

Ref No.	Part Number	Description	Qty	Remarks
21	JC1-F5103-00-00	HUB BEARING UNIT ASSY	2	
22	90114-12805-00	. .BOLT, SERRATION	4	
23	93306-204X0-00	. .BEARING	1	
24	93306-005Y3-00	. .BEARING	1	
25	90387-241M7-00	. .COLLAR	1	
26	93102-30083-00	. .OIL SEAL	1	
27	90208-14801-00	WASHER, CONICAL SPRING	2	
28	95602-14100-00	NUT, U	2	
29	JN6-F5118-01-00	COVER, HUB DUST	2	
30	90179-12262-00	NUT	8	
31	JC1-F5100-01-00	WHEEL ASSY (205/65-10 4P)	2	




 J0D1100-S130

# STEERING

Ref No.	Part Number	Description	Qty	Remarks
1	JW1-F3811-03-00	COLUMN, STEERING	1	
2	95812-08020-00	BOLT, FLANGE	4	
3	JU0-F3857-11-00	HOLDER	1	
4	JU0-F3828-10-00	ROD, STEERING	1	
5	JU0-F3857-11-00	HOLDER	1	
6	JN3-F3838-00-00	WHEEL, STEERING	1	
7	90185-12008-00	NUT, SELF-LOCKING	1	
8	92902-12200-00	WASHER	1	
9	95602-12200-00	NUT, SELF-Locking	2	
10	JW1-F3400-00-00	STEERING ASSY	1	
11	JW1-F387A-00-00	..GEAR,PINION	1	
12	JW1-F3183-00-00	..CIRCLIP	1	
13	JW1-F3812-00-00	..BEARING, STEERING	1	
14	JW1-F387E-00-00	..GEAR, RACK	1	
15	5UG-F387G-00-00	..COVER, ADJUST	1	
16	5UG-F387K-00-00	..SPRING, PRESSURE	1	
17	5UG-F387F-00-00	..PAD, PRESSURE	1	
18	5UG-F387J-00-00	..RING, STOPPER	1	
19	5UG-F3844-00-00	..SEAL	1	
20	5UG-F3489-00-00	..BAND	2	


CONTINUED ON NEXT FRAME >



  
JC06110-N140

# STEERING

Ref No.	Part Number	Description	Qty	Remarks
21	5UG-F3527-00-00	.SEAL, DUST 1	2	
22	JW1-F3837-00-00	.ROD, TIE 2	2	
23	JW1-F467K-00-00	.BUSH, CAP	1	
24	JW1-F3866-00-00	.CIRCLIP	1	
25	JW1-F3894-00-00	.WASHER, LOCK 1	2	
26	1P0-F3833-00-00	NUT 1	2	
27	JW8-23841-01-00	JOINT, UNIVERSAL 1	2	
28	90105-10847-00	BOLT, FLANGE	4	
29	JW1-F3822-01-00	JOINT 1	1	
30	97012-08030-00	BOLT	2	
31	92902-08600-00	WASHER, PLATE	2	
32	JW8-K8357-00-00	HOLDER 1	1	
33	JN6-K8358-01-00	HOLDER 2	1	
34	97702-40525-00	SCREW, TAPPING	2	
35	90201-04810-00	WASHER, PLATE	2	
36	90502-10013-00	SPRING, CONICAL	2	
37	90387-046N7-00	COLLAR	2	
38	JC0-K7762-00-00	LABEL, WARNING 2	1	




  
JC06110-N140

# FUEL TANK

Ref No.	Part Number	Description	Qty	Remarks
1	JC0-F4111-01-00	TANK, FUEL	1	
2	JW1-F4610-00-00	..CAP ASSY	1	
3	JW1-F4112-00-00	..PIPE	1	
4	JU5-F4375-00-00	..GROMMET	1	
5	J0B-F4217-00-00	COVER	1	
6	90450-54008-00	HOSE CLAMP ASSY	1	
7	B88-2817K-00-00	LABEL,FUEL	1	
8	JW1-F1738-00-00	BOLT	2	
9	90560-08251-00	SPACER	2	
10	J0D-13907-00-00	FUEL PUMP COMP.	1	
11	JC0-24491-00-00	BRACKET, FUEL PUMP	1	
12	1S3-24486-00-00	O-RING	1	
13	95302-06800-00	NUT, CROWN	6	
14	J0D-13971-00-00	PIPE, FUEL 1	1	
15	JW7-F312H-00-00	CLAMP	1	
16	7CC-F4170-01-00	CANISTER ASSY	1	
17	4WM-24180-00-00	ROLL OVER VALVE ASSY	1	
18	90464-40825-00	CLAMP	1	
19	J0B-F4314-00-00	PIPE 4	1	
20	J0B-F4316-00-00	PIPE 6	1	


CONTINUED ON NEXT FRAME >



  
J0D1100-S150

# FUEL TANK


Ref No.	Part Number	Description	Qty	Remarks
21	J0B-F4317-00-00	PIPE 7	1	
22	J0B-F419A-00-00	HOLDER	1	
23	JW7-K7329-00-00	RIVET	2	
24	90464-18246-00	CLAMP	1	
25	J0B-K8253-00-00	PAD, SILENCER 3	1	



 J0D1100-S150

# PEDAL WIRE

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-F6341-00-00	WIRE, BRAKE 1	1	
2	J0B-F6351-00-00	CABLE, BRAKE	1	
3	91702-10026-00	PIN, CLEVIS	3	
4	90468-20196-00	CLIP	3	
5	JW7-F312H-00-00	CLAMP	4	
6	JW8-F5681-10-00	EQUALIZER, BRAKE	1	
7	JN6-F5685-01-00	ROD	1	
8	90179-08822-00	NUT	1	
9	95307-08700-00	NUT	1	
10	90249-14129-00	PIN	1	
11	99001-09600-00	CIRCLIP	2	
12	91701-08018-00	PIN	2	
13	91490-25015-00	PIN. COTTER	2	




J0B1110-S150



# PEDAL ASSEMBLY

Ref No.	Part Number	Description	Qty	Remarks
1	JW8-F7850-31-00	PEDAL ASSY (L.H)	1	
2	JW9-F7200-21-00	..PEDAL, BRAKE	1	
3	JW8-F7814-21-00	...BUSH, PEDAL	2	
4	JW9-F5672-00-00	...PAD, PARKING PEDAL	1	
5	JW9-F5671-00-00	...PEDAL, PARKING BRAKE	1	
6	JW8-F7117-00-00	...BOLT, MAIN STAND	1	
7	JW8-F8363-00-00	...NUT	1	
8	JW8-F7416-00-00	...BOLT, FOOTREST	1	
9	JW8-F639N-00-00	...COLLAR	1	
10	JW8-F7218-00-00	...NUT	1	
11	JW8-F7113-00-00	...COLLAR, MAIN STAND	1	
12	JW9-F5666-00-00	...SECTOR, PARKING BRAKE	1	
13	JW8-F7121-00-00	...BUSH	1	
14	JW9-F7221-00-00	...SEAL, SHAFT	2	
15	JW8-F7322-00-00	...WASHER	1	
16	JW8-F3183-00-00	...CIRCLIP	1	
17	JW8-F7426-01-00	...SPRING, RETURN	1	
18	JW9-F7231-10-00	...ROD, BRAKE	1	
19	JW9-F7232-00-00	...END, ROD 2	1	
20	JW8-F7318-00-00	...NUT	2	

CONTINUED ON NEXT FRAME >




**FWD**  
JC23100-P170

# PEDAL ASSEMBLY

Ref No.	Part Number	Description	Qty	Remarks
21	JW8-F6314-00-00	...SPRING	1	
22	JW8-F639L-00-00	...BUSH 1	1	
23	JW9-F7228-00-00	...PIN, JOINT	1	
24	JW8-F8323-00-00	...WASHER, LEG SHIELD	1	
25	JW8-F5415-00-00	...CIRCLIP	1	
26	90386-12800-00	...BUSH	3	
27	JW8-F7825-01-00	...SPRING, RETURN	1	
28	JW8-F7119-00-00	...WASHER	2	
29	JW8-F8319-00-00	...WASHER	1	
30	JW9-F7245-10-00	..PAD, BRAKE PEDAL	1	
31	JW8-F7316-01-00	..SPRING, SIDE STAND	1	
32	JW8-F7217-00-00	..BOLT	1	
33	JW8-F7445-31-00	..PLATE 1	1	
34	JW8-F7213-20-00	..COLLAR	1	
35	JW8-F7853-10-00	..SHAFT, PEDAL 1	1	
36	JW9-F7871-10-00	..PEDAL, ACCELERATOR	1	
37	JW8-F7872-30-00	..ARM, ACCELERATOR PEDAL	1	
38	JW8-F7438-00-00	..PIN, CLEVIS	1	
39	JW8-F7434-00-00	..BOLT	1	
40	JW8-F7317-00-00	..BOLT	1	


CONTINUED ON NEXT FRAME >



FWD  
JC23100-P170

# PEDAL ASSEMBLY

Ref No.	Part Number	Description	Qty	Remarks
41	JW8-F7118-00-00	..NUT	1	
42	JW8-F815H-01-00	..SPRING	1	
43	JW8-F7814-21-00	..BUSH, PEDAL	2	
44	JW8-F4486-00-00	..O-RING	4	
45	JW9-F5673-00-00	..DAMPER, BRAKE	1	
46	JW9-F7246-20-00	..NAIL, BRAKE	1	
47	JW8-F8331-00-00	..BOLT, LEG SHIELD	2	
48	JW8-F4486-00-00	..O-RING	2	
49	95812-08020-00	BOLT, FLANGE	6	
50	J0B-F6311-00-00	CABLE, THROTTLE 1	1	
51	91702-05014-00	PIN, CLEVIS	1	
52	90468-10049-00	CLIP	1	
53	90508-16460-00	SPRING, TORSION	1	
54	90560-05001-00	SPACER	1	




FWD  
JC23100-P170

# BRAKE


Ref No.	Part Number	Description	Qty	Remarks
1	JW8-F7280-00-00	.BACKING PLATE ASSY 1	1	
2	JN9-W2536-00-00	...BRAKE SHOE SET	1	
3	J38-27204-00-00	...LEVER ASSY 1	1	
4	JW8-F7281-00-00	...SPRING, SHOE CLAMP	2	
5	J10-27282-00-00	...PIN, SHOE HOLD DOWN	2	
6	90506-20281-00	...SPRING, TENSION	1	
7	90506-14001-00	...SPRING, TENSION	1	
8	J55-27270-00-00	...ADJUSTER ASSY	1	
9	JW8-F7286-00-00	...COVER, DUST	1	
10	90201-121H9-00	...WASHER, PLATE	1	
11	90201-121H8-00	...WASHER, PLATE	1	
12	JW8-F7290-00-00	.BACKING PLATE ASSY 2	1	
13	JN9-W2536-00-00	...BRAKE SHOE SET	1	
14	J38-27205-00-00	...LEVER ASSY 2	1	
15	JW8-F7281-00-00	...SPRING, SHOE CLAMP	2	
16	J10-27282-00-00	...PIN, SHOE HOLD DOWN	2	
17	90506-20281-00	...SPRING, TENSION	1	
18	90506-14001-00	...SPRING, TENSION	1	
19	J55-27260-00-00	...ADJUSTER ASSY	1	
20	JW8-F7286-00-00	...COVER, DUST	1	

CONTINUED ON NEXT FRAME >



# BRAKE


Ref No.	Part Number	Description	Qty	Remarks
21	90201-121H9-00	...WASHER, PLATE	1	
22	90201-121H8-00	...WASHER, PLATE	1	
23	90105-082A0-00	BOLT, FLANGE	8	



 JOB1110-S170

# GOVERNOR

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-27951-00-00	LEVER, SPEED LIMITER	1	
2	95302-06600-00	NUT, HEXAGON	1	
3	90386-08141-00	BUSH	2	
4	90508-40678-00	SPRING, TORSION	1	
5	J38-27959-00-00	SCREW, ADJUSTING	1	
6	95602-06200-00	NUT, SELF-LOCKING	1	




  
J0B1110-S180

# PRIMARY SHEAVE

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-G6201-01-00	PRIMARY CLUTCH ASSY	1	
2	JW8-G6210-01-00	..PRIMARY FIXED SHEAVE COMP.	1	
3	J0B-G6220-01-00	..PRIMARY SLIDING SHEAVE COMP.	1	
4	JW8-G624A-00-00	...OIL SEAL 1	2	
5	JW8-G6253-00-00	...SLIDER	3	
6	JW8-G4189-00-00	...SCREW	3	
7	JW8-F135J-00-00	...NIPPLE	1	
8	JW8-G6251-21-00	..SPIDER	1	
9	JW8-G6205-22-00	..WEIGHT LINK ASSY	3	
10	JW8-G5618-00-00	...WASHER, 1	2	
11	90113-04803-00	...BOLT, SET	2	
12	JW8-G6236-20-00	..PIN, WEIGHT	3	
13	JW8-G6237-20-00	..PIN, WEIGHT 2	3	
14	90113-04803-00	..BOLT, SET	6	
15	JW8-G5618-00-00	..WASHER, 1	6	
16	JW8-G5621-00-00	..WASHER, 2	6	
17	J0B-G6231-00-00	..CAP	1	
18	JW8-G5282-00-00	..SCREW	3	
19	JW8-G6249-00-00	BOLT	1	
20	JW8-G7339-00-00	PLUG	1	


CONTINUED ON NEXT FRAME >



JC05110-M180

# PRIMARY SHEAVE

Ref No.	Part Number	Description	Qty	Remarks
21	J0D-G6241-00-00	BELT	1	




 JC05110-M180



# SECONDARY SHEAVE

Ref No.	Part Number	Description	Qty	Remarks
1	JW8-G6202-22-00	SECONDARY SHEAVE ASSY	1	
2	JW8-G6260-22-00	..SECONDARY FIXED SHEAVE COMP.	1	
3	JW8-G6270-21-00	..SECONDARY SLIDING SHEAVE COMP	1	
4	JW8-F135J-00-00	...NIPPLE	1	
5	JW8-G624B-00-00	...OIL SEAL 2	2	
6	JW8-G6284-00-00	..SEAT, SECONDARY SPRING	1	
7	JW8-E7688-00-00	..SHOE, RAMP	3	
8	JW8-G6159-00-00	..BOLT 3	3	
9	JW8-G5531-00-00	..CLIP, DRIVE SHAFT	1	
10	JW8-G6374-00-00	..COLLAR, SPRING	1	
11	JW8-G6275-10-00	..SPRING, CLUTCH 1	1	
12	JW8-G5677-00-00	..WASHER	1	
13	90209-08018-00	WASHER	1	
14	90105-08260-00	BOLT, FLANGE	1	
15	JW8-G5697-20-00	COLLAR	1	




  
JC05110-M190

# TRANSMISSION

Ref No.	Part Number	Description	Qty	Remarks
1	95812-10020-00	BOLT, FLANGE	6	
2	J0D-G6301-00-00	TRANSMISSION ASSY	1	
3	J0B-G633E-00-00	.BAR 1	1	
4	93306-303Y6-00	.BEARING	1	
5	JW8-E1923-00-00	.SLEEVE, GOVERNOR	1	
6	J0B-G2391-00-00	.NUT 1	13	
7	JU0-F722H-00-00	.RETAINER	1	
8	J0D-G6320-00-00	.INPUT SHAFT ASSY	1	
9	J0B-G6164-00-00	.BEARING 1	1	
10	J0B-G3127-00-00	.COLLAR	1	
11	J0B-G3812-00-00	.SEAL, DUST	2	
12	J0B-G6555-00-00	.BRACKET 2	1	
13	JU0-G6376-00-00	.SPRING SET	1	
14	90113-08803-00	...BOLT, SET	1	
15	90501-10852-00	...SPRING, COMPRESSION	1	
16	93500-06826-00	...BALL	1	
17	93102-25868-00	.OIL SEAL	1	
18	J0B-G580H-00-00	.BEARING ASSY	2	
19	90201-208H9-00	.WASHER, PLATE	1	
20	J0B-G6356-00-00	.GEAR, IDLER	1	


CONTINUED ON NEXT FRAME >



# TRANSMISSION


Ref No.	Part Number	Description	Qty	Remarks
21	90201-208J0-00	..WASHER, PLATE	1	
22	93606-10842-00	..PIN, DOWEL	2	
23	J0B-G1297-00-00	..WASHER, 1	2	
24	J0B-G6316-00-00	..GEAR, PINION 1	1	
25	J0B-G6326-00-00	..GEAR, WHEEL 1	1	
26	J0B-G633G-00-00	..SHAFT	1	
27	J0B-G6153-00-00	..COLLAR, GUIDE	1	
28	J0B-G638E-00-00	..BAR, SHIFT 2	1	
29	J0B-G638A-00-00	..BAR, SHIFT 1	1	
30	J0D-G6327-00-00	..GEAR, WHEEL 2	1	
31	J0B-G6314-00-00	..COVER, TRANSMISSION	1	
32	JN3-G6432-00-00	..STOPPER	1	
33	J0B-G1148-00-00	..BOLT	13	
34	93109-10820-00	..OIL SEAL	1	
35	JU0-F723F-00-00	..WASHER, SPECIAL	1	
36	JW8-F47E3-00-00	..CIRCLIP	1	
37	93104-11829-00	..OIL SEAL	1	
38	JW8-G5378-00-00	..NIPPLE, HOSE	1	
39	93306-007Y0-00	..BEARING	2	
40	J0B-G6410-00-00	..DIFFERENTIAL ASSY.	1	

CONTINUED ON NEXT FRAME >




# TRANSMISSION

Ref No.	Part Number	Description	Qty	Remarks
41	JC1-G2544-00-00	..BOLT	4	
42	90170-10840-00	..NUT	4	
43	J0B-G6355-00-00	..GEAR, PRIMARY	1	
44	J0B-G5148-00-00	..PLUG, DRAIN	1	
45	JN3-G6344-00-00	..SHIM, 0.76MM (0.030IN)	1	
46	JW8-G2541-00-00	PIPE 1	1	
47	J0B-G6556-00-00	BRACKET 3	1	
48	90105-08867-00	BOLT, FLANGE	2	



# SHIFTER & CABLES


Ref No.	Part Number	Description	Qty	Remarks
1	95602-08100-00	NUT, U	1	
2	J0B-G8330-00-00	CABLE END ASSY	1	
3	J0B-G6371-00-00	. .WIRE, SHIFT	2	
4	JW8-G6383-10-00	. .LEVER, SHIFT 2	1	
5	J0B-G6382-00-00	LEVER, SHIFT 1	1	
6	91702-06014-00	PIN, CLEVIS	2	
7	92902-06600-00	WASHER, PLATE	2	
8	91402-20012-00	PIN, COTTER	2	
9	JN3-G6381-00-00	KNOB, SHIFT	1	
10	JN3-G6376-00-00	SPRING SET	1	
11	90201-208S8-00	WASHER, PLATE	1	
12	90201-198S7-00	WASHER, PLATE	1	
13	99009-19400-00	CIRCLIP	1	
14	97602-04316-00	SCREW, PAN HEAD WITH WASHER	2	
15	J0B-G6372-00-00	BRACKET, SHIFT WIRE	1	
16	90105-06831-00	BOLT, FLANGE	3	
17	JN3-82617-01-00	SWITCH	1	
18	90465-06038-00	CLAMP	1	



 J0B1110-S220

## REAR AXLE & WHEEL


Ref No.	Part Number	Description	Qty	Remarks
1	J0B-F5310-01-00	HUB ASSY	2	
2	90114-12004-00	. .BOLT, SERRATION	4	
3	90179-20016-00	NUT	2	
4	90179-12262-00	NUT	8	
5	JC1-F5100-01-00	WHEEL ASSY (205/65-10 4P)	2	
6	JW3-G6521-00-00	.DRUM	2	
7	JW8-F5118-00-00	COVER, HUB DUST	2	
8	90201-20035-00	WASHER, PLATE	2	
9	J0B-F518F-00-00	DRIVE SHAFT ASSY	1	
10	J0B-F518G-00-00	DRIVE SHAFT ASSY	1	
11	93450-22119-00	CIRCLIP	2	



J0D1100-S240

# BUMPER


Ref No.	Part Number	Description	Qty	Remarks
1	J0B-K7510-00-00	FRONT BUMPER COMP.	1	
2	J0B-K8164-00-00	STAY, FRONT BUMPER (L.H)	1	
3	95812-08016-00	BOLT, FLANGE	2	
4	95812-08050-00	BOLT, FLANGE	2	
5	95302-08700-00	NUT, HEXAGON	2	
6	95822-06012-00	BOLT, FLANGE	4	
7	JW8-K7540-00-00	REAR BUMPER COMP.	1	
8	95602-10200-00	NUT, S/L FLANGE	2	



# BODY

Ref No.	Part Number	Description	Qty	Remarks
1	J0D-K8115-A0-00	COWL, FRONT	1	UR FOR BW1
1	J0D-K8115-00-00	COWL, FRONT	1	UR FOR DNBME
1	J0D-K8115-20-00	COWL, FRONT	1	UR FOR LNYM8
1	J0D-K8115-30-00	COWL, FRONT	1	UR FOR LNMP
1	J0D-K8115-40-00	COWL, FRONT	1	UR FOR DYNM2
1	J0D-K8115-70-00	COWL, FRONT	1	UR FOR DRMV
1	J0D-K8115-80-00	COWL, FRONT	1	UR FOR BMG
1	J0D-K8115-90-00	COWL, FRONT	1	UR FOR VPBM6
2	J0B-F4161-00-00	EMBLEM 1	1	
3	JU0-K7573-00-00	NUT, SPECIAL	2	
4	90105-06831-00	BOLT, FLANGE	1	
5	90269-06804-00	RIVET	2	
6	J0D-K8114-00-00	PANEL, FRONT	1	
7	90269-07803-00	RIVET	3	
8	J0B-K7768-00-00	LABEL, WARNING 8	1	ENGLISH
9	J0D-K8282-00-00	PLATE, SWITCH PANEL	1	
10	J0B-K835E-00-00	HOLDER, BEVERAGE	1	
11	90111-05805-00	BOLT,HEX. SOCKET BUTTON	1	
12	90183-05008-00	NUT, SPRING	1	
13	J0B-H2370-00-00	PLUG CAP ASSY	1	


CONTINUED ON NEXT FRAME >





# BODY


Ref No.	Part Number	Description	Qty	Remarks
14	J0D-H333B-00-00	REFLECTOR 1	1	
15	J0D-H334B-00-00	REFLECTOR, 2	1	
16	J0D-K8233-00-00	MAT, MAIN FLOOR 3	1	
17	90269-09003-00	RIVET	12	
18	J0B-K8273-00-00	COVER, HOLE	1	
19	J0B-K8243-00-00	MAT, REAR BODY SIDE (LH)	1	
20	90269-07803-00	RIVET	2	
21	J0B-K8244-00-00	MAT, REAR BODY SIDE (RH)	1	
22	90269-07803-00	RIVET	2	
23	J0B-K832F-00-00	GROMMET, ROOF SUPPORT 1	1	WITHOUT SUN ROOF
23	J0B-K832F-10-00	GROMMET, ROOF SUPPORT 1	1	WITH SUN ROOF
24	J0B-K832G-00-00	GROMMET, ROOF SUPPORT 2	1	WITHOUT SUN ROOF
24	J0B-K832G-10-00	GROMMET, ROOF SUPPORT 2	1	WITH SUN ROOF



# BODY 2

Ref No.	Part Number	Description	Qty	Remarks
1	J0D-K8111-A0-00	PANEL, BODY SHELL	1	UR FOR BW1
1	J0D-K8111-00-00	PANEL, BODY SHELL	1	UR FOR DNBME
1	J0D-K8111-20-00	PANEL, BODY SHELL	1	UR FOR LNYM8
1	J0D-K8111-30-00	PANEL, BODY SHELL	1	UR FOR LNMP
1	J0D-K8111-40-00	PANEL, BODY SHELL	1	UR FOR DYNAM2
1	J0D-K8111-70-00	PANEL, BODY SHELL	1	UR FOR DRMV
1	J0D-K8111-80-00	PANEL, BODY SHELL	1	UR FOR BMG
1	J0D-K8111-90-00	PANEL, BODY SHELL	1	UR FOR VPBM6
2	J0B-F3447-00-00	CLIP	1	
3	J0B-K814E-00-00	SEAL, BODY SIDE 1	1	
4	J0B-K814F-00-00	SEAL, BODY SIDE 2	1	
5	90269-07803-00	RIVET	3	
6	J0B-K8251-00-00	PAD, SILENCER 1	1	
7	J0D-K825G-00-00	PAD, SILENCER 13	2	
8	J0D-K8112-90-00	PANEL, BODY SHELL	1	UR FOR VPBM6
8	J0D-K8112-80-00	PANEL, BODY SHELL	1	UR FOR BMG
8	J0D-K8112-70-00	PANEL, BODY SHELL	1	UR FOR DRMV
8	J0D-K8112-40-00	PANEL, BODY SHELL	1	UR FOR DYNAM2
8	J0D-K8112-30-00	PANEL, BODY SHELL	1	UR FOR LNMP
8	J0D-K8112-20-00	PANEL, BODY SHELL	1	UR FOR LNYM8

CONTINUED ON NEXT FRAME >




**FWD**  
J0D1100-S270

# BODY 2

Ref No.	Part Number	Description	Qty	Remarks
8	J0D-K8112-00-00	PANEL, BODY SHELL	1	UR FOR DNBME
8	J0D-K8112-A0-00	PANEL, BODY SHELL	1	UR FOR BW1
9	J0B-F3447-00-00	CLIP	1	
10	J0B-K814E-00-00	SEAL, BODY SIDE 1	1	
11	J0B-K814F-00-00	SEAL, BODY SIDE 2	1	
12	90269-07803-00	RIVET	3	
13	J0B-K819H-00-00	SHELL, REAR BODY	1	
14	J0B-K814R-00-00	SEAL, BODY SIDE 3	1	
15	J0B-K814T-00-00	SEAL, BODY SIDE 4	2	
16	J0B-K814U-00-00	SEAL, BODY SIDE	2	
17	JW7-K7329-00-00	RIVET	2	
18	J0B-F1738-00-00	BOLT	4	
19	J0B-K8141-90-00	PANEL, INTERMEDIATE BODY	1	UR FOR VPBM6
19	J0B-K8141-70-00	PANEL, INTERMEDIATE BODY	1	UR FOR DRMV
19	J0B-K8141-80-00	PANEL, INTERMEDIATE BODY	1	UR FOR BMG
19	J0B-K8141-A0-00	PANEL, INTERMEDIATE BODY	1	UR FOR BW1
19	J0B-K8141-00-00	PANEL, INTERMEDIATE BODY	1	UR FOR DNBME
19	J0B-K8141-20-00	PANEL, INTERMEDIATE BODY	1	UR FOR LNYM8
19	J0B-K8141-30-00	PANEL, INTERMEDIATE BODY	1	UR FOR LNMP
19	J0B-K8141-40-00	PANEL, INTERMEDIATE BODY	1	UR FOR DYNM2

CONTINUED ON NEXT FRAME >




**FWD**  
J0D1100-S270

# BODY 2

Ref No.	Part Number	Description	Qty	Remarks
20	90269-07803-00	RIVET	8	
21	J0B-K8237-01-00	COVER, REAR FLOOR	1	
22	J0B-F3447-00-00	CLIP	4	
23	J0B-F1738-00-00	BOLT	2	
24	J0B-K8255-01-00	PAD, SILENCER 5	1	
25	J0B-F2873-01-00	SEAL 1	1	
26	J0B-F2874-01-00	SEAL 2	1	
27	J0D-F1781-10-00	EMBLEM 1	1	EXCEPT DYNAM2, BMG
27	J0D-F1781-00-00	EMBLEM 1	1	FOR DYNAM2, BMG
28	J0D-F1782-00-00	EMBLEM 2	1	FOR DYNAM2, BMG
28	J0D-F1782-10-00	EMBLEM 2	1	EXCEPT DYNAM2, BMG
29	JW1-K7741-00-00	INDICATOR 1	1	
30	JR1-K8139-00-00	CAP, END	1	
31	JN6-H2377-00-00	LABEL	1	
32	J0D-H360G-00-00	REFLECTOR 3	1	
33	J0D-H360H-00-00	REFLECTOR 4	1	
34	JW1-K8297-02-00	PLATE, CAUTION 1	1	
35	J0B-K817H-00-00	TRIM, SIDE PANEL 1	1	WITHOUT SUN ROOF
35	J0B-K817H-10-00	TRIM, SIDE PANEL 1	1	WITH SUN ROOF
36	J0B-K817J-00-00	TRIM, SIDE PANEL 2	1	WITHOUT SUN ROOF


CONTINUED ON NEXT FRAME >



  
J0D1100-S270

# BODY 2

Ref No.	Part Number	Description	Qty	Remarks
36	J0B-K817J-10-00	TRIM, SIDE PANEL 2	1	WITH SUN ROOF




WITHOUT SUN ROOF

 J0D1100-S270


# BODY FITTING

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-K8271-00-00	SERVICE LID, PEDAL	1	
2	J0B-K818A-00-00	PROTECTOR, SIDE PLATE	1	
3	90269-09003-00	RIVET	3	
4	90269-06804-00	RIVET	1	
5	J0B-K818B-00-00	PROTECTOR, SIDE PLATE 2	1	
6	90269-09003-00	RIVET	3	
7	90269-06804-00	RIVET	1	
8	J0B-K8191-00-00	PANEL, REAR FENDER 1	1	
9	90269-06804-00	RIVET	5	
10	J0B-K8192-00-00	PANEL, REAR FENDER 2	1	
11	90269-06804-00	RIVET	5	
12	J0B-K8197-01-00	FLAP, REAR FENDER	2	
13	J0B-K8187-00-00	FLAP, FRONT FENDER	1	
14	90464-76800-00	CLAMP	4	



# CARRIER


Ref No.	Part Number	Description	Qty	Remarks
1	J0B-K8423-00-00	SUPPORT, SEAT BACK	1	
2	90109-08002-00	BOLT	4	
3	JW1-K8340-00-00	LUGGAGE RACK ASSY., REAR	1	
4	92017-06040-00	BOLT, BUTTON HEAD	4	
5	J0B-K7389-00-00	WASHER	4	
6	90176-06008-00	NUT, CROWN	4	
7	JF2-K8356-00-00	PAD, BAG SUPPORT	1	
8	JN6-K8355-20-00	BAND	1	
9	JW1-K834G-00-00	HOLDER, RAKE SAND	1	
10	9708R-06020-00	BOLT	1	
11	90185-06836-00	NUT, SELF-LOCKING	1	
12	JN6-K8380-00-00	LOCK ASSY	2	
13	90159-06845-00	SCREW, WITH WASHER	4	
14	9299R-06200-00	WASHER	4	



J0B1110-S280


# REAR VIEW MIRROR

Ref No.	Part Number	Description	Qty	Remarks
1	JC0-F6280-01-00	REAR VIEW MIRROR ASSY (LEFT)	1	
2	JC0-F6291-00-00	.MIRROR	1	
3	JC0-F831W-10-00	.STAY, MIRROR 1	1	
4	JC0-F834N-10-00	.BRACKET, MIRROR 1	2	
5	JW1-K7387-10-00	.SCREW	2	
6	90201-068G7-00	.WASHER, PLATE	8	
7	JW1-K7217-00-00	.NUT, WIND SHIELD	4	
8	JC0-K7212-00-00	.BOLT, WIND SHIELD	2	



JC17100-P150






# SEAT

Ref No.	Part Number	Description	Qty	Remarks
1	JW9-H1674-00-00	BOLT	4	
2	J0B-K8427-00-00	HINGE, SEAT 2	2	
3	J0B-K8401-00-00	SEAT SUB-ASSY,CUSHION	1	
4	J0B-K8361-00-00	ARM REST 1	1	
5	J0B-F1738-00-00	BOLT	4	
6	J0B-K8362-00-00	ARM REST 2	1	
7	J0B-F1738-00-00	BOLT	4	
8	J0B-K8426-10-00	HINGE, SEAT 1	2	
9	90110-06125-00	BOLT, HEXAGON SOCKET HEAD	4	
10	JW1-K8402-10-00	SEAT SUB ASSY, BACK	1	
11	90119-06808-00	BOLT, WITH WASHER	4	



J0B1110-S290

# STARTING MOTOR




JY27010-L400

Ref No.	Part Number	Description	Qty	Remarks
1	JN6-H1100-04-00	STARTER GENERATOR ASSY	1	
2	J10-H1157-10-00	...BEARING 1	1	
3	J10-H1158-10-00	...BEARING 2	1	
4	J10-81159-10-00	...HOLDER, BEARING	1	
5	JN6-H1110-10-00	..STATOR ASSY	1	
6	JN6-H1160-10-00	...FIELD COIL ASSY	1	
7	J10-81148-10-00	...SCREW SET 4	2	
8	9530N-06600-00	....NUT,HEX	2	
9	9290N-06600-00	...WASHER	1	
10	92907-06100-00	....WASHER, SPRING	2	
11	J10-81146-10-00	...SCREW 2	4	
12	JN6-H1165-00-00	..BRACKET, STARTER GENERATOR 1	1	
13	J10-H1166-10-00	..BRACKET, STARTER GENERATOR 2	1	
14	J10-81147-10-00	..SCREW SET 3	2	
15	9530N-06600-00	....NUT,HEX	2	
16	9290N-06600-00	...WASHER	1	
17	92907-06100-00	....WASHER, SPRING	2	
18	JN6-H1119-00-00	..BRUSH HOLDER ASSY	1	
19	JF2-H1111-00-00	...BRUSH	4	
20	JN6-H1113-00-00	....SPRING, BRUSH	4	

CONTINUED ON NEXT FRAME >

# STARTING MOTOR




JY27010-L400

Ref No.	Part Number	Description	Qty	Remarks
21	J10-81115-10-00	...WIRE, LEAD	2	
22	9850N-05016-00	...SCREW, PAN HEAD	2	
23	9850N-04010-00	...SCREW, PAN HEAD	4	
24	J10-81129-10-00	..COVER, BRUSH	3	
25	J10-81139-10-00	..COVER, BRUSH 2	1	
26	J10-H1145-10-00	..SCREW 1	2	
27	9290N-06600-00	..WASHER	2	
28	JN3-H1661-00-00	..SPACER	1	
29	JN6-H1161-00-00	..PULLEY	1	
30	90179-16889-00	..NUT	1	
31	9850N-05018-00	..SCREW, PAN HEAD	3	

# HEAD & TAIL LIGHT


Ref No.	Part Number	Description	Qty	Remarks
1	J0D-H4110-00-00	HEADLIGHT UNIT ASSY	1	
2	J0D-H4300-00-00	..HEADLIGHT ASSY	1	
3	J0D-H411T-00-00	..HOLDER, 1	1	
4	J0D-H4385-00-00	..CAP,1	1	
5	J0D-H5490-00-00	..LIGHT CONTROL UNIT	1	
6	J0D-H4526-00-00	..SCREW	4	
7	J0D-H4726-00-00	..SCREW	3	
8	J0D-H3547-00-00	..COVER, SOCKET	1	
9	J0D-H4524-00-00	..SCREW, LENS FITTING	2	
10	J0D-H4195-00-00	..RING, RETAINING	1	
11	90183-08800-00	NUT, SPRING	3	
12	J0D-H4170-00-00	HEAD LIGHT UNIT ASSY	1	
13	J0D-H4300-00-00	..HEADLIGHT ASSY	1	
14	J0D-H411U-00-00	..HOLDER, 2	1	
15	J0D-H4386-00-00	..CAP,2	1	
16	J0D-H5490-00-00	..LIGHT CONTROL UNIT	1	
17	J0D-H4526-00-00	..SCREW	4	
18	J0D-H4726-00-00	..SCREW	3	
19	J0D-H3547-00-00	..COVER, SOCKET	1	
20	J0D-H4524-00-00	..SCREW, LENS FITTING	2	

CONTINUED ON NEXT FRAME >



# HEAD & TAIL LIGHT


Ref No.	Part Number	Description	Qty	Remarks
21	J0D-H4195-00-00	..RING, RETAINING	1	
22	90183-08800-00	NUT, SPRING	3	
23	J0D-H4710-00-00	TAILLIGHT UNIT ASSY	1	
24	J0D-H431U-00-00	..HOLDER	1	
25	J0D-H4700-00-00	..TAILLIGHT ASSY	1	
26	JC0-H4514-00-00	...BULB	1	(12V-7W/27W)
27	J0D-H4718-00-00	..GROMMET	1	
28	90183-08800-00	NUT, SPRING	2	
29	J0D-H4730-00-00	TAILLIGHT UNIT ASSY	1	
30	J0D-H4387-00-00	..HOLDER	1	
31	J0D-H4700-00-00	..TAILLIGHT ASSY	1	
32	JC0-H4514-00-00	...BULB	1	(12V-7W/27W)
33	J0D-H4718-00-00	..GROMMET	1	
34	90183-08800-00	NUT, SPRING	2	



# ELECTRICAL 1


Ref No.	Part Number	Description	Qty	Remarks
1	5CA-85886-00-00	SENSOR, AIR TEMPRATURE	1	
2	5CA-14435-00-00	GROMMET	1	
3	95812-12030-00	BOLT, FLANGE	2	
4	JW1-H1170-11-00	TENSIONER ASSY	1	
5	95822-08020-00	BOLT, FLANGE	2	
6	90109-08827-00	BOLT	1	
7	95702-08500-00	NUT, FLANGE	1	
8	92012-06030-00	BOLT, BUTTON HEAD	1	
9	95302-06600-00	NUT, HEXAGON	1	
10	JN6-H1171-11-00	BRACKET, STARTER GENERATOR	1	
11	95822-08020-00	BOLT, FLANGE	2	
12	JW1-H1173-02-00	BELT	1	
13	JC0-85650-10-00	ROTOR ASSY	1	
14	JB2-81670-00-00	PICK-UP ASSY	1	
15	90480-20564-00	GROMMET	1	
16	95822-06016-00	BOLT, FLANGE	2	
17	1S4-82310-00-00	IGNITION COIL ASSY	1	
18	JC0-82316-00-00	BRACKET, IGNITION COIL	1	
19	95822-06016-00	BOLT, FLANGE	2	
20	95302-18600-00	NUT, HEXAGON	1	

CONTINUED ON NEXT FRAME >



# ELECTRICAL 1


Ref No.	Part Number	Description	Qty	Remarks
21	90201-18620-00	WASHER, PLATE	1	
22	90280-04052-00	KEY, WOODRUFF	1	
23	JN6-82370-00-00	PLUG CAP ASSY	1	
24	JE8-82372-00-00	SEAL, PLUG CAP	1	
25	JT0-85720-00-00	OIL LEVEL GAUGE ASSY	1	
26	95822-06012-00	BOLT, FLANGE	3	
27	JT0-85724-00-00	CLAMP	1	
28	JT0-15362-00-00	PLUG, OIL LEVEL	1	
29	93210-15414-00	O-RING	1	
30	4P9-83591-00-00	THERMO UNIT	1	
31	J0B-H591A-01-00	ENGINE CONTROL UNIT ASSY	1	
32	J0B-H5546-00-00	BAND	1	



# ELECTRICAL 2

Ref No.	Part Number	Description	Qty	Remarks
1	JW1-H2133-00-00	SCREW, FITTING	2	
2	J55-H2136-00-00	PLATE, BATTERY FITTING	1	
3	92902-06200-00	WASHER	2	
4	95702-06500-00	NUT, FLANGE	2	
5	J0B-H2115-00-00	WIRE, PLUS LEAD	1	
6	J0B-H2116-01-00	WIRE, MINUS LEAD	1	
7	J0B-H2117-00-00	WIRE, LEAD	1	
8	J0D-H2590-01-00	WIRE HARNESS ASSY	1	
9	JW6-H554E-00-00	..FUSE (10A)	2	
10	JW6-H554E-20-00	..FUSE (25A)	1	
11	JW6-H554E-10-00	..FUSE (15A)	1	
12	J0D-H2151-00-00	..FUSE	1	
13	J0B-82149-01-00	WIRE, LEAD 3	1	
14	JW1-H1950-00-00	RELAY ASSY	1	
15	90179-05807-00	..NUT	2	
16	90179-08824-00	..NUT	2	
17	90105-06831-00	BOLT, FLANGE	2	
18	JF2-81910-10-00	VOLTAGE REGULATOR ASSY	1	
19	90105-06870-00	BOLT, FLANGE	1	
20	JF7-82817-22-00	SWITCH	1	

CONTINUED ON NEXT FRAME >






# ELECTRICAL 2


Ref No.	Part Number	Description	Qty	Remarks
21	97602-05225-00	SCREW, PAN HEAD WITH WASHER	2	
22	JR1-H3383-02-00	BUZZER	1	
23	JN6-H3386-01-00	STAY, BUZZER	1	
25	1TP-81950-00-00	RELAY ASSY (1TP-00)	1	
26	5EA-81952-00-00	. .HOLDER, RELAY	1	
27	90461-14108-00	CLAMP	1	
28	90464-09823-00	CLAMP	1	
29	90464-20005-00	CLAMP	3	
30	90464-48800-00	CLAMP	3	
31	90119-06868-00	BOLT, WITH WASHER	1	
32	5UG-F2465-10-00	HOLDER	1	
33	1NS-F1338-00-00	CLAMP	3	
34	90464-40825-00	CLAMP	2	
35	90464-76800-00	CLAMP	2	
36	90105-08867-00	BOLT, FLANGE	1	
37	4LR-83371-11-00	HORN	1	
38	JR6-H270X-00-00	SWITCH	1	
39	95822-06016-00	BOLT, FLANGE	1	
40	95702-06500-00	NUT, FLANGE	1	
41	JC0-82519-00-00	WIRE, EARTH LEAD	1	

CONTINUED ON NEXT FRAME >




## ELECTRICAL 2

Ref No.	Part Number	Description	Qty	Remarks
42	95822-06012-00	BOLT, FLANGE	1	
43	J0D-H21E0-01-00	USB ASSY	1	
44	90119-06868-00	BOLT, WITH WASHER	2	
45	JW6-H2510-00-00	MAIN SWITCH ASSY	1	
46	JU6-H2511-10-00	. .KEY, MAIN SWITCH	2	
47	5UG-H2579-00-00	. .CAP, KEY	1	
48	JU6-H2569-00-00	. .NUT, MAIN SWITCH	1	
49	JC0-H351C-10-00	GAUGE 1	1	
50	JN6-H351C-10-00	GAUGE 1	1	AP
51	JW1-H1128-00-00	. .CLAMP	1	AP
52	J0B-F4881-00-00	BRKT., METER	1	AP
53	JW1-H2386-10-00	EXTENSION, WIRE HARNESS	1	AP
54	JW7-K7329-00-00	RIVET	1	AP
55	90464-12836-00	CLAMP	1	AP



# ALTERNATE FOR WINDSHIELD

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-K7200-20-00	WINDSHIELD ASSY	1	UR CLEAR
1	J0B-K7200-30-00	WINDSHIELD ASSY	1	UR SMOKE
2	J0B-K7458-00-00	. .LABEL, WARNING	1	
3	J0B-K7173-20-00	. .LEVER, LATCH 1	2	
4	J0B-K7258-00-00	. .SCREW, 2	4	
5	J0B-K7237-00-00	. .GROMMET	2	
6	J0B-K7247-00-00	. .GROMMET, W/S 2	2	
7	J0B-K7257-00-00	. .GROMMET, W/S 3	2	
8	J0B-K7238-00-00	. .DAMPER	2	
9	J0B-K7218-00-00	. .WASHER 1	2	
10	J0B-K7217-00-00	. .NUT, WIND SHIELD	4	
11	J0B-K7219-00-00	. .WASHER 2	2	
12	J0B-K7240-20-00	. .WIND SHIELD HARDWARE KIT 1	1	
13	J0B-K7227-20-00	PACKING, WIND SHIELD	1	




  
J0D1100-S360

# ALTERNATE FOR SUN ROOF

Ref No.	Part Number	Description	Qty	Remarks
1	J0B-K84A0-00-00	SUN TOP KIT	1	UR AP TAN
1	J0B-K84A0-10-00	SUN TOP KIT	1	UR AP BLACK
2	J0B-K84A2-00-00	. .HARDWARE KIT, SUN TOP	1	
3	J0B-K8312-00-00	. . .SUPPORT, SUN ROOF 1	2	
4	JW1-K8388-00-00	. . .BOLT, ROOF 1	4	
5	JW1-K8313-01-00	. . .SUPPORT, SUN ROOF 2	2	
6	J0B-K8388-00-00	. . .BOLT, ROOF 1	4	
7	JU0-K8388-00-00	. . .BOLT, ROOF 1	8	
8	JW1-F1549-01-00	. . .WASHER, FENDER MOLD	16	
9	JU0-K8398-00-00	. . .NUT, ROOF 1	8	
10	JW1-K7387-00-00	. . .SCREW	4	
11	JW1-K8314-10-00	. .COVER, SUN ROOF	1	UR TAN
11	JW1-K8314-20-00	. .COVER, SUN ROOF	1	UR BLACK
12	JW1-K8214-00-00	. .GRIP, HAND	2	
13	JU0-K8388-00-00	. .BOLT, ROOF 1	4	
14	JW1-F1549-01-00	. .WASHER, FENDER MOLD	8	
15	JU0-K8398-00-00	. .NUT, ROOF 1	4	
16	J0B-F417A-00-00	. .DRAIN TUBE ASSY	1	
17	J0B-F413G-00-00	. . .TUBE, DRAIN	1	
18	J0B-F413J-00-00	. . .TUBE, DRAIN 2	1	


CONTINUED ON NEXT FRAME >



**FWD**  
J0B1110-S340

# ALTERNATE FOR SUN ROOF

Ref No.	Part Number	Description	Qty	Remarks
19	JW1-F414G-10-00	SEAL	2	




  
JOB1110-S340

**PARTS CATALOG  
GOLF CAR  
2017 DRIVE<sup>2</sup> DR2A17 PTV  
(J0D1)**


# 1 TITLE PAGE

Ref No.	Part Number	Description	Qty	Remarks
---------	-------------	-------------	-----	---------

Applicable Serial No.  
Engine Serial No.



Frame Serial No.



**STARTING SERIAL NO.  
DRIVE<sup>2</sup> DR2A17 PTV  
J0D-000101**